


Quick Start Guide


1

1




- Charging of the DVD player only possible in the power-off mode.
- Le lecteur de DVD peut être chargé en mode hors tension uniquement.
- El reproductor de DVD sólo se puede cargar en el modo apagado.
- Der DVD-Player kann nur im Power Off-Modus geladen werden

2




2

1




2




3


1



2




3




4

DVB^T
 TERRESTRIAL


1




2




3



5



6



© 2009 Koninklijke Philips Electronics N.V.
 All rights reserved.



Be responsible
 Respect copyrights

SY/ZYL-0914

